

**SONY®**

2-698-598-11(2)

# ***Wireless Stereo Headset***

---

Operating Instructions



***DR-BT10CX***

©2006 Sony Corporation

# WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

To reduce the risk of fire, do not cover the ventilation of the apparatus with newspapers, tablecloths, curtains, etc. And do not place lighted candles on the apparatus.

To reduce the risk of fire or electric shock, do not place objects filled with liquids, such as vases, on the apparatus.

Connect the AC power adaptor to an easily accessible AC outlet. Should you notice an abnormality in the AC power adaptor, disconnect it from the AC outlet immediately.



Hereby, Sony Corp., declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For details, please access the following URL:  
<http://www.compliance.sony.de/>



**Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)**

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.

Other trademarks and trade names are those of their respective owners.

MPEG Layer-3 audio coding technology and patents licensed from Fraunhofer IIS and Thomson.

---

# Table Of Contents

<b>Welcome!</b> .....	<b>4</b>
3 steps to BLUETOOTH function .....	5
<b>Location and Function of Parts</b> .....	<b>6</b>
<b>Charging the unit</b> .....	<b>7</b>
<b>Pairing</b> .....	<b>9</b>
What is pairing? .....	9
Procedures of pairing .....	9
<b>Wearing the headset</b> .....	<b>11</b>
<b>Indications of BLUETOOTH function</b> ..	<b>12</b>
<b>Listening to music</b> .....	<b>13</b>
<b>Calling</b> .....	<b>15</b>
Controlling the BLUETOOTH mobile phone – HFP, HSP ..	17
<b>Calling while playing back music</b> .....	<b>18</b>
<b>Disposing of the unit</b> .....	<b>19</b>
<b>Precautions</b> .....	<b>20</b>
<b>What is BLUETOOTH technology?</b> .....	<b>22</b>
<b>Troubleshooting</b> .....	<b>23</b>
<b>Initializing the unit</b> .....	<b>24</b>
<b>Specifications</b> .....	<b>25</b>


---

# Welcome!

Thank you for purchasing this Sony Wireless Stereo Headset. This unit uses BLUETOOTH™ wireless technology.

- You can enjoy music from your BLUETOOTH device capable of transmitting music.
- You can enjoy hands-free talking with your BLUETOOTH mobile phone inside your bag.
- You can charge the unit using the supplied battery charging stand.

For details on BLUETOOTH technology, see page 22.



## 3 steps to BLUETOOTH function


### Pairing (each device)

First, register (“pair”) a BLUETOOTH device (mobile phone, etc.) and this unit with each other. Once pairing is established, there is no need for pairing again.

BLUETOOTH  
mobile phone,  
etc.



Pairing



Wireless Stereo  
Headset

→ Page 9

### Listening to music

#### BLUETOOTH connection

Operate the BLUETOOTH device to make BLUETOOTH connection.

Connection



A2DP

→ Page 13

### Calling

#### BLUETOOTH connection

When the unit is turned on, the unit starts making the BLUETOOTH connection to the recognized mobile phone automatically.

Connection



HFP

HSP

→ Page 15

### Listening to music


You can listen to music played on the BLUETOOTH device.



→ Page 13 - 14


### Talking on the phone

You can make and receive a call by operating unit.



→ Page 16 - 17

## Location and Function of Parts



**1 Multi function button**

Controls various call functions.

**2 Indicator (red)**

Indicates the power status of the unit.

**3 Indicator (blue)**

Indicates the communication status of the unit.

**4 POWER button**

**5 Earpieces**

**6 VOL - button**

**7 VOL + button**

**8 Microphone**

**9 RESET button**

**10 Holding clip**


Adjust the holding clip to the desired angle and clip to your pocket or collar.

**11 Contact point**


# Charging the unit

The unit contains a rechargeable Lithium-Ion battery, which should be charged before using for the first time.


## 1 Connect the supplied AC power adaptor with the battery charging stand.



## 2 Connect the supplied AC power adaptor to an AC outlet.



## 3 Put the unit on the battery charging stand.



### Note

If the holding clip is turned, the unit cannot be set on the battery charging stand and charging does not start. Turn the holding clip back to the original position before charging.

Rest the unit on the battery charging stand so that the unit's contact point meets the contact pin on the battery charging stand, and make sure that the indicator (red) lights up.

Charging is completed in about 3 hours\* and the indicator (red) goes off automatically.

\* Time required for empty battery to recharge.

### Tip

When charging the battery, the unit is turned off automatically.

**Continued 7**

## Caution

If this unit detects a problem while charging, the indicator (red) may turn off, although charging is not complete.

Check for the following causes:

- Ambient temperature exceeds the range of 0 °C – 40 °C (32 °F – 104 °F).
- There is a problem with the battery.

In this case, charge again within the above-mentioned temperature range. If the problem persists, consult your nearest Sony dealer.

## Notes

- If the battery is not used for a long time, battery may be quickly depleted, however, after a few recharges, battery life will improve.
- If the life of the built-in rechargeable battery drops to half the normal length, the battery should be replaced. Consult your nearest Sony dealer for replacement of the rechargeable battery.
- Avoid exposure to temperature extremes, direct sunlight, moisture, sand, dust or mechanical shock. Never leave in a car parked in the sun.
- Use only the supplied AC power adaptor. Do not use any other AC power adaptor.

## Usage hours\*

Status	Approx. usage hours
Communication time (including music playback time) (up to)	11 hours
Standby time (up to)	100 hours

\* Time stated above may vary, depending on ambient temperature or conditions of use.

## Checking the remaining battery

When pressing the POWER button while the unit is turned on, the indicator (red) flashes. You can check the remaining battery by the number of times the indicator (red) flashes.

Indicator (red)	Status
3 times	Full
2 times	Mid
1 time	Low (needs to charge)

## Note

You cannot check the remaining battery immediately after the unit is turned on, or while pairing.

## When the battery is almost empty

The indicator (red) flashes slowly automatically.

When the battery becomes empty, a beep sounds and the unit will turn off automatically.



# Pairing

## What is pairing?


BLUETOOTH devices need to be “paired” with each other beforehand.

Once BLUETOOTH devices are paired, there is no need for pairing again, except in the following cases:

- When pairing information is deleted after repair, etc.
- When this unit is paired with 9 or more devices.  
This unit can be paired with 8 BLUETOOTH devices; if a new device is paired after 8 devices have been paired, the device whose latest connection time is the oldest among the 8 paired devices is replaced by the new one.
- When recognition of the unit by the device to be connected is deleted.
- When this unit is initialized.  
All pairing information is deleted.

## Procedures of pairing

- 1 Place the connecting device within 1 m (3 ft) of this unit.**
- 2 Press and hold the POWER button for 7 seconds or more to standby for pairing while the unit is turned off.**



### Notes

- After about 3 seconds, power is turned on and the indicator (blue) and indicator (red) flash together twice. Keep the button pressed without releasing until both indicators start flashing together, then release the button. This unit enters into pairing mode.
- If pairing is not established within about 5 minutes, pairing mode will be cancelled and this unit will turn off. In this case, start over from step **1**.

### **3 Perform pairing procedure on the connecting device to detect this unit.**

The list of detected devices appears on the display of the connecting device. This unit is displayed as “DR-BT10CX.”

#### **Note**

If “DR-BT10CX” is not displayed, repeat from step **1**.

### **4 Select “DR-BT10CX” on the display of the connecting device.**

### **5 If Passcode\* input is required on the display of a connecting device, input “0000.”**

Pairing is complete when the indicator (blue) flashes slowly. The message standing for “Pairing complete” appears on the display of some BLUETOOTH devices.

\* Passcode may be called “Passkey,” “PIN code,” “PIN number,” or “Password.”

#### **Note**

Passcode of this unit is fixed at “0000.” This unit cannot be paired with a BLUETOOTH device whose Passcode is not “0000.”

### **6 Start the BLUETOOTH connection from the BLUETOOTH device.**

This unit memorizes the device as the latest connected device. Some BLUETOOTH devices may connect with the unit automatically when pairing is complete.

### **When pairing with a BLUETOOTH device that cannot display a list of detected devices or that has no display**

You may pair the device by setting both this unit and the connecting device to pairing mode. For details, refer to the operating instructions supplied with the connecting device.

#### **Tips**

- To pair with other BLUETOOTH devices, repeat steps **1** to **5** for each device.
- To delete all pairing information, see “Initializing the unit” (page 24).

---

## Wearing the headset


Wear the earpiece marked **(R)** in your right ear and the one marked **(L)** in your left ear.



- ① Turn the holding clip to the desired angle and clip to your pocket or collar.


### How to install the earbuds correctly

If the earbuds do not fit your ears correctly, low-bass sound may not be heard. To enjoy better sound quality, adjust the earbuds position to sit on your ears comfortably or push them into the inside of your ears so that they fit your ears snugly. If the earbuds do not fit your ears, try ones of other size.



### How to use the holder

Store the earpieces. It prevents the cord from tangling if you store the earbuds.




# Indications of BLUETOOTH function

**B** : Indicator (blue)

**R** : Indicator (red)

Status		Flashing patterns
Pairing	Searching	<b>B</b> ● - ● - ● - ● - ● - ● - ● - ● - ● - ...
		<b>R</b> ● - ● - ● - ● - ● - ● - ● - ● - ● - ...
Connecting	Connectable	<b>B</b> ● - - - ● - - - ● - - - ● - - - ● - - - ● ... <b>R</b> -
	Connecting	<b>B</b> ● - - - ● - - - ● - - - ● - - - ● - - - ● ... <b>R</b> ● - - - ● - - - ● - - - ● - - - ● - - - ● ...
Connected	HFP/HSP or A2DP (standby for receiving audio signal)	<b>B</b> ● - - - - - - - - - ● - - - - - ... <b>R</b> -
	HFP/HSP and A2DP (standby for receiving audio signal)	<b>B</b> ● - ● - - - - - - - - ● - ● - - - ... <b>R</b> -
Music	Listening	<b>B</b> ●● - - - - - - - - - ●● - - - ... <b>R</b> -
	Listening during standby for telephone call	<b>B</b> ●●● - - - - - - - - - ●●● - - - ... <b>R</b> -
Phone	Incoming call	<b>B</b> ●●●●●●● ... <b>R</b> -
	Talking	<b>B</b> ●● - - - - - - - - - ●● - - - ... <b>R</b> -
	Calling while playing back music	<b>B</b> ●●● - - - - - - - - - ●●● - - - ... <b>R</b> -

## Listening to music



Check the following before operating the unit.

- The BLUETOOTH device is turned on.
- Pairing of this unit and the BLUETOOTH device is complete.
- The BLUETOOTH device supports the transmitting music function (profile: A2DP).

### 1 Press and hold the POWER button for about 3 seconds while the unit is turned off.

The indicator (blue) and indicator (red) flash together twice and the unit is turned on.

#### Note

Do not press and hold the POWER button for more than 7 seconds, otherwise pairing mode is entered.

### 2 Make the BLUETOOTH connection (A2DP) from a BLUETOOTH device to this unit.

Refer to the operating instructions supplied with the BLUETOOTH device on how to operate it.

### 3 Start playback on the BLUETOOTH device.

#### Notes

- When you play music by connecting the unit to a BLUETOOTH device using HSP (Headset Profile)\*, sound quality will not be high. For better sound, change the BLUETOOTH connection to A2DP (Advanced Audio Distribution Profile)\* by operating the BLUETOOTH device.
- This unit cannot control music playback functions of the connected device.

\* For detail on profiles, see page 22.

#### To adjust the volume

Press the VOL + or - button while listening to the music.

#### Tips

- When the volume level is low, raise the volume of the connected device. The sound will be clearer.
- Volume level for listening to music and calling can be set independently.

#### Note

You cannot adjust the volume of the BLUETOOTH device by the unit VOL buttons.

## To stop use

**1 Terminate the BLUETOOTH connection by operating the BLUETOOTH device.**


**2 Press and hold the POWER button for about 3 seconds.**

The indicator (blue) and indicator (red) light up together, and the unit turns off.

### **Tip**

When you finish playing music, the BLUETOOTH connection may terminate automatically, depending on the BLUETOOTH device.

# Calling



Check the following before operating the unit.

- The BLUETOOTH function is active on the mobile phone.
- Pairing of this unit and the BLUETOOTH mobile phone is complete.

## 1 Press and hold the POWER button for about 3 seconds while the unit is turned off.

The indicator (blue) and indicator (red) flash together twice, the unit turns on and then this unit automatically connects to the last BLUETOOTH mobile phone that was used.

### Note

Do not press and hold the POWER button for more than 7 seconds, otherwise pairing mode is entered.

### Tip

This unit will stop trying to connect to the BLUETOOTH mobile phone after 1 minute. In such a case, press the multi function button to try to connect again.

When you want to connect the unit to a different BLUETOOTH mobile phone from the last time, follow the procedure in “When this unit does not connect to a BLUETOOTH mobile phone automatically.”

## When this unit does not connect to a BLUETOOTH mobile phone automatically

### 1 Make the BLUETOOTH connection (HFP or HSP) from the BLUETOOTH mobile phone to this unit.

Refer to the manual supplied with your BLUETOOTH mobile phone for operation details.

The list of recognized devices appears on the display of the BLUETOOTH mobile phone. This unit is displayed as “DR-BT10CX.”

When you use the BLUETOOTH mobile phone features both HFP (Hands-free Profile) and HSP (Headset Profile)\*, set to HFP.

\* For details on profiles, see page 22.

## Note

When listening to music by operating this unit connected to a BLUETOOTH mobile phone, make the BLUETOOTH connection by operating the BLUETOOTH mobile phone. This cannot be done with the multi function button.

## To call

### 1 Use the buttons on your mobile phone when making a call.

If no sound is heard through this unit, press the multi function button.

## Tip

You can call in the following way, depending on the BLUETOOTH mobile phone. Refer to the manual supplied with your mobile phone on operating details.

- When not communicating, you can call using the voice-dial function by pressing the multi function button.
- You can call a specific number by pressing the multi function button for about 2 seconds.

## To receive a call

When the telephone is ringing, ring tone will be heard through the unit.

### 1 Press the multi function button on the unit.

The ring tone differs in the following ways, depending on your mobile phone.

- ring tone set on the unit
- ring tone set on the mobile phone
- ring tone set on the mobile phone only for BLUETOOTH connection

## Note

If you pressed the call button on the BLUETOOTH mobile phone, some BLUETOOTH mobile phones may have handset use priority. In this case, set to talk with the unit by pressing and holding the multi function button for about 2 seconds, or by operating the BLUETOOTH mobile phone. For details, refer to the manual supplied with your BLUETOOTH mobile phone.

## To adjust the volume

Press the VOL + or – button.

## Tips

- You cannot adjust the volume when not communicating.
- Volume level for calling and listening to music can be set independently.

## To terminate a call

You can end a call by pressing the multi function button on the unit.

## To stop use

### 1 Terminate BLUETOOTH connection by the BLUETOOTH mobile phone.

### 2 Press and hold the POWER button for about 3 seconds to turn off the power.

The indicator (blue) and indicator (red) light up together, and the unit turns off.



## Controlling the BLUETOOTH mobile phone – HFP, HSP

The operation of the buttons on this unit varies depending on your mobile phone.

HFP (Hands-free Profile) or HSP (Headset Profile) is used for BLUETOOTH mobile phone. Refer to the operating instructions supplied with your BLUETOOTH mobile phone on supported BLUETOOTH profiles or how to operate.

- \*1 Some functions may not be supported depending on the BLUETOOTH mobile phone.
- \*2 This may vary, depending on the BLUETOOTH mobile phone.
- \*3 Some functions may not be supported when calling using the BLUETOOTH mobile phone.

### HFP (Hands-free Profile)

Status	Multi function button	
	Short Press	Long Press
Standby	Start Voice Dial	Last number redial
Voice Dial active	Cancel Voice Dial	–
Outgoing call	End outgoing call	–
Incoming call	Answer	Reject
During call	End call	Change active device

### HSP (Headset Profile)

Status	Multi function button	
	Short Press	Long Press
Standby	–	Dial*1
Outgoing call	End outgoing call*1	End outgoing call or change active device to headset*2
Incoming call	Answer	–
During call	End call*3	Change active device to headset

---

## Calling while playing back music

If the BLUETOOTH connection is active with the mobile phone, you can switch the unit to call even when listening to music.

Before starting, see “Calling” (page 15) on operating details.

### To call while playing back music

- 1 Press the multi function button while playing back music (page 15), or operate your BLUETOOTH mobile phone to make a telephone call.**

If no sound is heard through this unit, press and hold the multi function button for about 2 seconds.

### To receive a call while playing back music

The sound through the unit changes to a ring tone automatically.

- 1 Press the multi function button and talk.**

After finishing the call, press the multi function button. This unit is switched back to music playback.


### If the sound does not change to a ring tone automatically

- 1 Stop music playback.**
- 2 When ringing, press the multi function button and talk.**


## Disposing of the unit

For environmental conservation, be sure to remove the built-in rechargeable battery from the unit before disposing, and dispose of the battery appropriately.


### 1 Remove 2 screws.



### 3 Remove the rechargeable battery and dispose of it.



### 2 Open the case and detach the connector.



---

# Precautions

## On BLUETOOTH communication

- BLUETOOTH wireless technology operates within a range of about 10 m (about 30 ft).  
Maximum communication range may vary depending on obstacles (person, metal, wall, etc.) or electromagnetic environment.
  - The aerial of this unit is built into the unit. The sensitivity of BLUETOOTH communication will improve by placing a connected BLUETOOTH device near the unit.
  - The following conditions may affect the sensitivity of BLUETOOTH communication.
    - There is an obstacle such as a person, metal, or wall between this unit and BLUETOOTH device.
    - A device using 2.4 GHz frequency, such as a wireless LAN device, cordless telephone, or microwave oven, is in use near this unit.
  - Because BLUETOOTH devices and wireless LAN (IEEE802.11b/g) use the same frequency, microwave interference may occur and resulting in communication speed deterioration, noise, or invalid connection if this unit is used near a wireless LAN device. In such as case, perform the following.
    - Use this unit at least 10 m (about 30 ft) away from the wireless LAN device.
    - If this unit is used within 10 m (about 30 ft) of a wireless LAN device, turn off the wireless LAN device.
    - Install this unit and BLUETOOTH device as near to each other as possible.
  - Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other
- BLUETOOTH devices in the following locations, as it may cause an accident.
- where inflammable gas is present, in a hospital, train, airplane, or a petrol station
  - near automatic doors or a fire alarm
- This unit supports security capabilities that comply with the BLUETOOTH standard to provide a secure connection when the BLUETOOTH wireless technology is used, but security may not be enough depending on the setting. Be careful when communicating using BLUETOOTH wireless technology.
  - We do not take any responsibility for the leakage of information during BLUETOOTH communication.
  - Connection with all BLUETOOTH devices cannot be guaranteed.
    - A device featuring BLUETOOTH function is required to conform to the BLUETOOTH standard specified by BLUETOOTH SIG, and be authenticated.
    - Even if the connected device conforms to the above mentioned BLUETOOTH standard, some devices may not be connected or work correctly, depending on the features or specifications of the device.
    - While talking on the phone hands free, noise may occur, depending on the device or communication environment.
  - Depending on the device to be connected, it may require some time to start communication.

## On the supplied AC power adaptor

- Use the AC power adaptor supplied with this unit. Do not use any other AC power adaptor since it may cause the unit to malfunction.



Polarity of the plug

- If you are not going to use this unit for a long time, unplug the AC power adaptor from the AC outlet. To remove the AC power adaptor from the wall outlet, grasp the adaptor plug itself; never pull the cord.

## Others

- Do not place this unit in a place exposed to humidity, dust, soot or steam, subject to direct sunlight, or in a car waiting at a traffic signal. It may cause a malfunction.
- Using the BLUETOOTH device may not function on mobile phones, depending on radio wave conditions and location where the equipment is being used.
- If you experience discomfort after using the BLUETOOTH device, stop using the BLUETOOTH device immediately. Should any problem persist, consult your nearest Sony dealer.
- Do not allow small children to use this unit.
- Listening with this unit at high volume may affect your hearing. For traffic safety, do not use this unit while driving or cycling.
- If the earbuds become wet, wipe it with a dry towel before using.

- Clean the earbuds by hand-washing with a mild detergent solution. Remove the earbuds when you clean them. After cleaning, dry the earbuds well before use.
- The earbuds may deteriorate due to long-term storage or use.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

---

# What is BLUETOOTH technology?

BLUETOOTH wireless technology is a short-range wireless technology that enables wireless data communication between digital devices, such as a computer or digital camera. BLUETOOTH wireless technology operates within a range of about 10 m (about 30 ft). Connecting two devices as necessary is common, but some devices can be connected to multiple devices at the same time. You do not need to use a cable for connection since BLUETOOTH is a wireless technology, nor is it necessary for the devices to face one another, such is the case with infrared technology. For example, you can use such a device in a bag or pocket. BLUETOOTH technology is an international standard supported by millions of companies all over the world, and employed by various companies worldwide.

## Communication System and Compatible BLUETOOTH Profiles of this unit

Profile is standardization of the function for each BLUETOOTH device specification. This unit supports the following BLUETOOTH version and profiles:

Communication System : BLUETOOTH Specification version 2.0

Compatible BLUETOOTH Profiles:

- A2DP (Advanced Audio Distribution Profile): Transmitting or receiving audio content of high-quality.
- HSP (Headset Profile)\*: Talking on the phone/Operating the phone.
- HFP (Hands-free Profile)\*: Talking on the phone/Operating the phone by hands-free.

\* When you use a BLUETOOTH mobile phone supported by both HFP (Hands-free Profile) and HSP (Headset Profile), set to HFP.

### Note

To be able to use the BLUETOOTH function, the BLUETOOTH device to be connected requires the same profile as the unit's.

Note also that even if the same profile exists, devices may vary in function depending on their specifications.

---

# Troubleshooting

If you run into any problems using this unit, use the following checklist. Should any problem persist, consult your nearest Sony dealer.

## Common

### The unit is not turned on.

- ➔ Charge the battery of the unit.
- ➔ The unit is not turned on while charging. Remove the unit from the battery charging stand and then turn on the unit.

### Pairing cannot be done.

- ➔ Bring this unit and the BLUETOOTH device closer together.

### Cannot make the BLUETOOTH connection.

- ➔ Check that this unit is turned on.
- ➔ Check that the BLUETOOTH connecting device is turned on and the BLUETOOTH function is on.
- ➔ Connection with the BLUETOOTH device may not be memorized on this unit. Make the BLUETOOTH connection from the BLUETOOTH device to this unit soon after pairing is complete.
- ➔ This unit or BLUETOOTH connecting device is in sleep mode.
- ➔ The BLUETOOTH connection is terminated. Make the BLUETOOTH connection again.

### Distorted sound

- ➔ Ensure that this unit is not receiving interference from a wireless LAN, other 2.4 GHz wireless device, or microwave oven.
- ➔ Re-position this unit.

### The correspondence distance is short. (Sound skips.)

- ➔ If a device that generates electromagnetic radiation, such as a wireless LAN, other BLUETOOTH device(s), or a microwave oven is nearby, move away from such sources.

### Cannot operate the unit. (Connection has hung up.)

- ➔ Press the RESET button. Pairing information is not deleted by this operation.

## When listening to music

### No sound

- ➔ Check that both this unit and the BLUETOOTH device are turned on.
- ➔ Check that both this unit and the BLUETOOTH device are making the BLUETOOTH connection, A2DP (Advanced Audio Distribution Profile).
- ➔ Check that music is being played back by the BLUETOOTH device.
- ➔ Check that the volume of the unit is not set too low.
- ➔ Check that the volume of the BLUETOOTH device is not set too low if the BLUETOOTH device has a volume control.
- ➔ Pair this unit and BLUETOOTH device again.

## Low sound level

- ➔ Turn up the volume of this unit.
- ➔ Turn up the volume of the BLUETOOTH device if the BLUETOOTH device has a volume control.

## Low sound quality

- ➔ Switch the BLUETOOTH connection to A2DP (Advanced Audio Distribution Profile) when HSP (Headset Profile) is set.

## When calling

### The recipient's voice cannot be heard.

- ➔ Check that both this unit and the BLUETOOTH mobile phone are turned on.
- ➔ Check the connection between this unit and the BLUETOOTH mobile phone.
- ➔ Check that output of the BLUETOOTH mobile phone is set for this unit.
- ➔ Check that the volume of the unit is not set too low.
- ➔ Check that the volume of the BLUETOOTH mobile phone is not set too low if the BLUETOOTH mobile phone has a volume control.
- ➔ If you are listening to music using this unit, stop playback, press the multi function button and talk.

### Low sound from recipient

- ➔ Turn up the volume of this unit.
- ➔ Turn up the volume of the BLUETOOTH mobile phone if the BLUETOOTH mobile phone has a volume control.

---

## Initializing the unit

You can reset this unit to its default (such as volume setting) and delete all pairing information.

- 1 If this unit is turned on, press and hold the POWER button for about 3 seconds to turn off this unit.**
- 2 Press and hold the POWER button and multi function button together for about 7 seconds.**

The indicator (blue) and indicator (red) flash together four times, and this unit is reset to the default setting. All pairing information is deleted.



# Specifications

## General

### Communication system

BLUETOOTH Specification version 2.0

### Output

BLUETOOTH Specification Power Class 2

### Maximum communication range

Line of sight approx. 10 m (30 ft)\*<sup>1</sup>

### Frequency band

2.4 GHz band (2.4000 GHz – 2.4835 GHz)

### Modulation method

FHSS

### Compatible BLUETOOTH Profiles\*<sup>2</sup>

A2DP (Advanced Audio Distribution Profile)

HSP (Headset Profile)

HFP (Hands-free Profile)

### Supported codecs\*<sup>3</sup>

SBC\*<sup>4</sup>, MP3

### Supplied accessories

AC power adaptor (1)

Battery charging stand (1)

Earbuds (S × 2, M × 2, L × 2)

Holder (1)

\*<sup>1</sup> The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, aerial's performance, operating system, software application, etc.

\*<sup>2</sup> BLUETOOTH standard profiles indicate the purpose of BLUETOOTH communication between devices.

\*<sup>3</sup> Codec: Audio signal compression and conversion format

\*<sup>4</sup> Subband Codec

## Headset

### Power source

DC 3.7 V: Built-in lithium-ion rechargeable battery

### Dimensions

Approx. 25 × 51 × 29 mm  
(1 × 2 × 1 <sup>3</sup>/<sub>16</sub> in) (w/h/d)

### Cord (from unit to earpiece)

Approx. 0.3 m (11 <sup>7</sup>/<sub>8</sub> in)

### Mass

Approx. 27 g (1.0 oz) including earpieces and cord

Earpieces: Approx. 4 g (0.15 oz) not including cord

### Rated power consumption

1.5 W

## Receiver

### Type

Closed, dynamic

### Driver unit

9 mm dome type (CCAW adopted)

### Reproduction frequency range

20 – 20,000 Hz

## Microphone

### Type

Omni directional, electret condenser

### Effective frequency range

100 – 4,000 Hz

Design and specifications are subject to change without notice.





<http://www.sony.net/>

Printed in Malaysia



\* 2 6 9 8 5 9 8 1 1 \* (2)